



Gus's
Kitchen & Bath
LIMITED

Choose Gus's
For Kitchens, Bathrooms
& Fine Furniture!

www.guskitchenandbath.com

810 Rye Street, Unit C, Peterborough, Ontario K9J 6W9

Phone: 705-876-6030 Fax: 705-876-6951

Email: guskitchenandbath@hotmail.com Website: www.guskitchenandbath.com

INSTALLATION INSTRUCTIONS FOR UNDERMOUNT SINKS AND GRANITE TOPS

*** Required for Installation - 100% Clear Kitchen and Bath Silicone**

UNDERMOUNT SINKS

- Turn granite upside down
- Place a bead of silicone on the lip of the sink
- Adhere the sink to the underside of the granite top
- Place a second bead of silicone on the outer rim of the sink
- Allow to dry

GRANITE TOPS

- Place a bead of silicone along the outside edges of the vanity
- Position the granite top onto the vanity ensuring a 1/2" overhang on each end
- Allow to dry

- The back-splash is secured in the same fashion
- Use a bead of silicone along the bottom of the back-splash
- Position the back-splash along the back edge of the granite top
- Allow to dry

- We recommend sealing the granite top with any good granite sealer

60" DOUBLE SINK VANITIES

Some cutting of wood may be necessary for the fitment on the sinks using jigsaw

If you have any trouble with the installation of the sinks into the 60" vanities, please call Gus at (705) 876-6030